TENSION FABRIC DISPLAY





Connect tubes together

To assemble, use the provided allen wrench to secure the longest vertical poles onto the black steel base. Next, secure the bottom horizontal support pole. Snap on the remaining vertical poles, and the top curved bar to finish hardware assembly. Tilt down the hardware display to slip on the pillowcase type fabric.





Cover tension frame with fabric